MICHELLE
REMOTE CONTROLLER

ON: luminaire ON permenantly.

OFF: luminaire OFF, detection OFF.

After power disconnection,
the luminaire will memorize last setting
and restore it when power is resumed.

Default setting: 90s duration after
detection 50lux lux level in dusk/dawn time
100% sensitivity level.

Reset   ON/OFF

Duration after detection.

10s   3min   10min

Dusk and dawn lux level setting
or disable this function for all-day detection.

15Lux   50Lux   Disable

Sensitivity reduce to 50%.

10%   30%   Sensor 50%

Lumen level setting in the ECO mode
(energy saving mode).

6H   12H   24H/24H

Duration timer of ECO mode.
The timer will re-start after detection.
24H/24H means the timer is set to be 7x24.

Reset: 90s - 50Lux - 100% sensitivity